



Beltis Fire Pit

With its gently textured profile, the new Beltis Fire Pit kit builds a 12" high fire pit and includes an insert and comes available in two classic colours.

- Inside Measurement: 813mm (32")
- Outside Measurement: 1092mm (43")
- Height: 305mm (12")
- Inner ring included
- Pallet Weight: 1763lbs / 800kg
- Fire pit requires 36 blocks- your kit may include additional blocks that are not required to complete your fire pit.

Colours:



Shadow Blend



Earth Blend



Beltis Fire Pit Kit

Installation Information

- Time to Complete - Approximately 1 hour
- Degree of Difficulty - Beginner

Additional Materials Required

- Tamper
- Household Level
- 2 Bags of Leveling Sand
- 2 Tubes of Concrete Adhesive
- Caulk Gun
- 3 Bags of Gravel Rock
- Shovel
- Optional Marking Paint or Chalk

Installation:



For a lawn, mark a 49" diameter circle with marking paint then go to step 2. For a patio, use chalk instead of paint then skip to step 5.



Remove all sod, roots and dirt to a depth of 2 inches inside the circle.



Level the soil and remove high spots as best possible. Tip: Use a household level to help.



Add 1.5"-2" of paver base and level. Moisten with water to aid compaction then use a tamper to pack the entire area firm. Add .5"-1" more of paver base and level again.



Place wall stones on top of paver base, firmly touching each stone creating a circle. Make sure each stone is leveled front to back and side to side and even with adjacent stones.



For the second layer of stone, lay the middle of each stone over the joint made between the sides of the two stones underneath it. Place stones firmly together and level as before.



Attach the two layers of stone together using concrete adhesive. Remove one top stone and lay 2 liberal beads of adhesive near the center of the stone. Place stone back and press down firmly. Repeat for all 2nd layer stones.



Lay the third layer the same way you laid the second. The third layer joints should line up with the first layer joints. Adhere the stones with concrete adhesive as you did in step 7.



After all stones are set, install the fire pit insert. The insert's top lip should rest on the inside edge of the fire pit stones.



After the adhesive cures, pour gravel rock into the bottom of the fire pit, leveling it as you go. The gravel should reach the bottom of the insert ring.

Please ensure you follow all local bylaws regarding fire pits, their installation, placement and usage in your community.

Always observe open fire and fire pit safety rules. Expocrete, a division of Oldcastle Building Products Canada, Inc. accepts no liability for the use of any fire pit built with our materials.



Beltis Fire Pit
Earth Blend



Expocrete an Oldcastle® company

British Columbia Alberta Saskatchewan Manitoba

For more info visit: Belgard.com | Expocrete.com

Get Social

